



Disassembling Nokia 2366i Front Cover

This guide shows you how to remove the front cover of the Nokia 2366i.

Written By: Kristen



INTRODUCTION

This guide shows you how to remove the front cover of the phone so that you can access the internal components found there.



TOOLS:

- [Spudger](#) (1)
-

Step 1 — Battery



- Turn off the phone.
- ⓘ Position the phone so that the back side is in view.

Step 2



- Apply pressure on the cover while simultaneously sliding the cover downward.
- Remove the back battery cover.

Step 3



- Insert the spudger between the base of the phone and the phone battery.
- Position the phone so that the battery won't fall out of the phone.
- Carefully lift the battery out of the phone.
- ❗ The battery lifts out of the phone easily.

Step 4 — Front Cover



- Keep the phone closed.
- ❗ Hold the phones sideways with the front cover of the phone facing up.

Step 5



- Find the slight crease on the side that divides the display assembly in half.
 - Slowly wedge the spudger into the crease.
- ⚠ It's a little difficult to perform this step because the crease is narrow. Do not rush because you may damage the phone

Step 6



- Run the spudger all along the crease while lifting up.
- Separate the front cover from the front base.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-25 09:41:56 PM.